

INSTALLATION INSTRUCTIONS

PART NUMBER: CSUV21-100 GRILLE GUARD

APPLICATION: 2021+ CHEVY SUBURBAN / TAHOE



QTY	PARTS LIST
1	CSUV21-100/PB
6	½" x 1 ½" HEX HEAD BOLTS
2	½" x 4-½" HEX HEAD BOLTS
10	½" HEX NUTS
10	½" LOCK WASHERS
18	½" FLAT WASHERS
2	3/8" x 4" HEX HEAD BOLTS
4	3/8" FLAT WASHERS
2	3/8" NYLON LOCK NUTS
2	7/16" X 1 ½" HEX HEAD BOLT
2	7/16" LOCK WASHER
2	7/16" FLAT WASHER
1	CSUV21-100 LEFT FRAME BRACKET
1	CSUV21-100 RIGHT FRAME BRACKET
2	CSUV21-100 RIGHT FRAME PLATE
2	CSUV21-100 LEFT FRAME PLATE

****Inspect bumper and all parts prior to installation.**

-WARNING-

Special care should be exercised in the handling and installation of our products.

- Always wear safety glasses during installation process to avoid personal injury.
- Use extreme caution when lifting and securing product into place.
- Never position yourself directly under product during installation.
- Insulate all exposed wiring and electrical connectors.
- Always securely mount wiring harness to bumper and vehicle.
- Products may require minor trimming for proper fit.
- Periodically check nuts and bolts to make sure they remain tight.

CSUV21-100 GRILLE GUARD


2021+ CHEVY SUBURBAN / TAHOE

Note- Leave all bolts finger tight until all the components are mounted

1. Remove the (2) 18mm bolts that retain the tow hooks in the frame.
2. Cut the plastic bumper fascia at the tow hook hole as shown in the picture.
3. Install the provided frame plates on each side of both frame rails, use the 3/8" x 4" bolt to secure the plates. The protruding oval piece of the plate engages the oval shape on the frame.
4. Slide the frame bracket inside the frame rail and secure it using the 1/2" hardware
5. Mount the Thunder Struck grille guard to the frame brackets.
6. Align the grille guard with the body lines of the vehicle and tighten all the bolts.

CSUV21-100 GRILLE GUARD / PUSH BAR

2021+ CHEVY SUBURBAN / TAHOE



NOTE: DO NOT TIGHTEN BOLTS UNTIL ALL OF THEM ARE STARTED